

SKILL SQUARES

V103 US

1. DIP SWITCH SETTING

DIP SWITCH 1		1	2	3	4	5	6	7	8
DEMO MUSIC	YES	OFF							
	NO	ON							
GAME SPEECH	YES		OFF						
	NO		ON						
BOOK PASSWORD	YES			OFF					
	NO			ON					
DOUBLE UP	YES				OFF				
	NO				ON				

DIP SWITCH 2		1	2	3	4	5	6	7	8
SCORE BOX	NO	OFF							
	YES	ON							
PLAY SCORE	NO		OFF						
	YES		ON						
HAND COUNT	NO			OFF					
	YES			ON					
WAIT TIME	10				OFF	OFF			
	15				ON	OFF			
	20				OFF	ON			
	30				ON	ON			
SKILL MODE	NO						OFF		
	YES						ON		
GAME NAME	SKILL							OFF	
	BINGO							ON	

* The "SYSTEM LIMIT" will automatically transfer into "No" when the "HAND COUNT" adjusted
 Remark: for normal operation please set Chance Level on OFF (low) & ON (high) for Casino

2. SYSTEM SETUP (Push Record key to select the following item):

SYSTEM ADJUSTMENT		
CONTENTS	DEFAULT	SETTING SELECTION
MAX. BET	50	5, 10, 20, 30, 40, 50, 60, 70, 80, 90, 100
MIN. BET	10	1, 5, 10, 20, 30, 40, 50
COIN RATE	5	
TICKET RATE	20	1, 2, 3, 4, 5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 80, 100, 200, 250,
KEYIN RATE	100	400, 500, 1000
KEYOUT RATE	1	
GAME TICKET	1	1, 2, 3, 4, 5, 8, 10, Continuous
CREDIT LIMIT	1000	1000, 2000, 5000, 9000, 10000, 20000, 50000, 90000, NO
CHANCE ADJUSTMENT		
MAIN GAME RATE	LEVEL 5	LEVEL 1 (95%), LEVEL 2 (90%), LEVEL 3 (85%), LEVEL 4 (80%), LEVEL 5 (75%), LEVEL 6 (70%), LEVEL 7 (65%), LEVEL 8 (60%), LEVEL 9 (55%)
CHANCE LEVEL	LOW	LOW, MIDDLE, HIGH
DOUBLE UP RATE	LEVEL 5	LEVEL 1 (95%), LEVEL 2 (90%), LEVEL 3 (85%), LEVEL 4 (80%), LEVEL 5 (75%), LEVEL 6 (70%), LEVEL 7 (65%), LEVEL 8 (60%), LEVEL 9 (55%)

3. CONNECTION DIAGRAM FOR 36 + 10 PINS

TYPE A, B	
PARTS SIDE	SODER SIDE
VIDEO RED	1 VIDEO GREEN
VIDEO BLUE	2 VIDEO SYNC
SPEAKER	3 VIDEO GND
	4
	5
	6
TICKET OUT	7
TICKET SW.	8
START/TAKE	9
	10
D/ SMALL	11
PLAY	12
A/ TAKE	13
B/ DOUBLE-UP	14
	15
	16
C/ BIG	17
	18
COIN	18 KEY IN
	19 COIN C
BOOK	20 TEST
PAYOUT	21 KEY OUT
	22 HOPPER SW.
COIN METER	23
KEY IN METER	24
	25
	26
PAYOUT METER	27
KEYOUT METER	28
LAMP (START)	29
LAMP (D/ SMALL)	30
LAMP (PLAY)	31
LAMP (A)	32
LAMP (B/ DOUBLE-UP)	33
LAMP (C/ BIG)	34
	35
GND	36 GND

PARTS SIDE		SODER SIDE	
GND	1	GND	
GND	2	GND	
+5V	3	+5V	
+5V	4	+5V	
+12V	5	+12V	
	6		
SSR (+12V)	7		
	8		
GND	9	GND	
GND	10	GND	