

SUPER POKER

V305US

SW1	LEVEL	1	2	3	4	5	6	7	8
HOLD MODE	HOLD WIN	OFF							
	AUTO HOLD	ON							
MAX PLAY	8		OFF	OFF					
	10		ON	OFF					
	50		OFF	ON					
MIN. PLAY	100		ON	ON					
	1				OFF	OFF			
	5				ON	OFF			
TICKET PAYOUT	10				OFF	ON			
	20				ON	ON			
PAYOUT MODE	OFF						OFF		
	ON						ON		
SYSTEM LIMIT	MANUAL							OFF	
	AUTO							ON	
	OFF								OFF
	ON								ON

SW2	LEVEL	1	2	3	4	5	6	7	8
MAIN RATE	50%	OFF	OFF	OFF					
	60%	ON	OFF	OFF					
	65%	OFF	ON	OFF					
	70%	ON	ON	OFF					
	75%	OFF	OFF	ON					
	80%	ON	OFF	ON					
	85%	OFF	ON	ON					
	90%	ON	ON	ON					
	75%				OFF	OFF			
W-UP RATE	80%				ON	OFF			
	85%				OFF	ON			
SHOW DISCARD	HOLD				ON	ON			
	DISCARD						OFF		
PASSWORD	OFF						ON		
	ON							ON	
W-UP GAME	NO							OFF	
	YES							ON	

SW3	LEVEL	1	2	3	4	5	6	7	8
HAND COUNT	NO	OFF							
	YES	ON							
PLAY SCORE	NO		OFF						
	YES		ON						
BOX SCORE	NO				OFF	OFF			
	YES				ON	ON			
	10 TIMES				ON	ON			

PARTS SIDE	1	2	3	4	5	6	7	8	9	10	SOLDER SIDE
GND											GND
GND											GND
+5V											+5V
+5V											+5V
+12V											+12V
COUNTER POWER											
HOPPER CONTROL											
GND											GND

PARTS SIDE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	SOLDER SIDE
VIDEO RED																																				VIDEO GREEN	
VIDEO BLUE																																				VIDEO SYNC	
SPEAKER																																			GND		
START 1/2 W-UP																																					
HOLD 1 SMALL																																					
HOLD 5 PLAY 2 W-UP																																					
HOLD 4 TAKE																																					
HOLD 3 W-UP																																					
HOLD 2 BIG																																					
COIN A																																				KEY IN	
OPERATOR (RECORD)																																				COIN C	
PAYOUT																																				TEST	
COIN A METER																																				KEY OUT	
KEY IN METER																																				TICKET SWITCH	
COIN C METER																																					
OUT METER																																					
LAMP: START 1/2 W-UP																																					
LAMP: HOLD 1 SMALL																																					
LAMP: HOLD 5 PLAY 2 W-UP																																					
LAMP: HOLD 4 TAKE																																					
LAMP: HOLD 3 W-UP																																					
LAMP: HOLD 2 BIG																																					
ATTENDANT																																					
GND																																				GND	

SYSTEM SETUP:

COIN RATE	1, 2, 4, 5, 10, 15, 20, 25, 40, 50, 60, 75, 80, 100, 200, 250, 400,
KEY IN RATE	500, 1000
KETOUT RATE	500, 1000
TICKET RATE	1, 2, 3, 4, 5, 8, 10, CONTINUOUS
GAME TICKET SET	CONTINUOUS